

CowboyStudio Photo Tent Storage Instructions

This document contains step-by-step instructions for folding one of our photo tents for storage. Your kit should include:

- One (1) photo tent
- Four (4) backgrounds
- One (1) carrying case

Refer to Figure 1 for the items included in the instructional kit. Our instructions start with a fully assembled photo tent, as shown in Figure 2.

Step 1: Remove the background from the photo tent by detaching the Velcro fasteners. Fold to a small size that will fit in the carrying case and put aside.

Step 2: Face the opening of the tent away from you and push one of the top corners down into the opposite bottom corner, as shown in Figure 3.

Step 3: Fold the remaining outer corners together, as illustrated in Figure 4, until you have a flat square.

Step 4: Grab the outer edge of two opposite sides. Twist your wrists in opposite directions as shown in Figure 5 and Figure 6. When finished twisting, you should have a smaller circle, as shown in Figure 7.

Step 5: Place the folded photo tent and 4 backgrounds into the carrying case and zip to close as shown in Figure 8.



Figure 1




Figure 2




Figure 3




Figure 4




Figure 5



Figure 6




Figure 7



Figure 8